

BRAKES

04-62 Hydraulic Pipes - Front Brakes	Quantity	Part No	
Right Hand Steering		Triumph	Rimmer Bros
Pipe assembly - rear master cylinder to PDWA valve	1	309204	
Pipe assembly - front master cylinder to PDWA valve	1	309203	
PDWA valve - Pressure Differential Warning	1	155071	155071
PDWA valve warning light switch	A/R	149971	149971
PDWA valve repair kit	A/R		155071RK
Bolt	1	HB709	SH604091
Washer - plain	1	WP7	GHF331
Washer - lock	1	WL207	GHF331
Nut	1	HN2007	GHF200
Pipe assembly - PDWA switch to LH brake hose	1	309217	
Brake hose	1	GBH211	GBH211
Brake hose gasket	1	107072	23220A
Washer	1	WN709	GHF323
Nut - lock	1	516614	516614
Clip	2	623312	GHF1192
Pipe assembly - PDWA switch to RH brake hose	1	309218	
Brake hose	1	GBH211	GBH211
Brake hose gasket	1	107072	23220A
Washer	1	WN709	GHF323
Nut - lock	1	516614	516614
Front pipe kit - right hand steering	1		RS1101
Front pipe kit - left hand steering	1		RS1101LHD