

TRIUMPH & LUCAS PART NUMBERS

05-16 Alternator - 11ACR To LD20000	Part No				
	Triumph	Lucas			
		1971	1972	1973	1987 Supersession
Alternator	213121	23521	23521		LRA119C
Fan	147990	54216148	54216148	54216148	
Pulley	154334	54219467	54219467		54202784
Bracket - drive end		54216382	54216382		
Bearing kit - drive end		54219685	54219685		UMB111
Rotor assembly		54218740	54218740		UFB101
Slip ring		54214541	54214541		UAB103
Stator		54216171	54216171		UJB113
Heatsink with cathode base diodes	516059	54217551	54217551		UBB102
Heatsink with anode base diodes	605405	54219249	54219249		UBB103
Brush box assembly		54216365	54216365		
Brush set		54215076	54215076		ULB109
Bracket - slip ring end		54218312	54218312		Not Serviced
Bearing kit - slip ring end		54219553	54219553		UMB110
Sleeve - slip ring end		54216330	54216330		Obsolete
Collar - distance		54216329	54216329		Not Serviced
Terminal kit		54219292	54219292		Obsolete
Fixing bolt		54111219	54111219		Not Serviced
Sundry parts kit	519457	54219682	54219682		Obsolete
Ignition warning light - Type 3AW					
Regulator control - Type 4TR		37423E	37423E		NCB144
Ignition control relay - Type 16RA		33294	33294A		