

## TRIUMPH & LUCAS PART NUMBERS

05-23 Coil, Leads & Plugs	Part No				
	Triumph	Lucas			
		1971	1972	1973	1987 Supersession
Ignition coil - to engine LF20250 approx	154272	45232A/D	45232A/D/E		DLB102
Ignition coil - from engine LF20250 approx to LF28553	158830	45243		45243A/B	DLB102
Ignition coil - from engine LF28554	UKC3555	45266			DLB102
Ballast resistor - to engine LF20000	134176	47222	47222		