

TRIUMPH & LUCAS PART NUMBERS

| 05-45 Ignition Switch & Master Lighting Switch | Part No | | | | |
|---|---------|--------|--------|----------|----------------------|
| | Triumph | Lucas | | | |
| | | 1971 | 1972 | 1973 | 1987 Supersession |
| Ignition switch - all markets except USA to LD20000 | 219060 | 39382A | 39383A | | Not Serviced |
| Ignition switch - home markets from LD20000 | 218500 | | | 30401A | |
| Ignition switch - European markets from LD20000 | | | | 30416A | Obsolete |
| Ignition switch - USA to LD20000 | 216385 | | 39382A | | |
| Ignition switch - USA from LD20000 | 219059 | | | 39911A | Obsolete |
| Ignition switch - from ? | TKC0452 | | | | |
| Master light switch - to LD20000 | 152432 | 39482A | 39482A | 39482A | |
| Master light switch - from LD20001 | 154807 | | | 54033632 | |
| Master light switch - LHS | 628408 | | | 39258B | |
| Master light switch knob - RHS to LD20000 | 626365 | | | | |
| Master light switch knob - RHS from LD20001 | 628407 | | | 54323377 | |
| Master light switch knob - USA to LF11277 | 626366 | | | | |
| Master light switch knob - USA from LF11278 | 631314 | | | | |
| Master light switch knob - LHS | 628408 | | | | |