


# ENGINE - Clutch Housing / Automatic Transmission Adaptor and Sump



**NOTE**

- \* Only required when Automatic Transmission is fitted
- † Not required when Automatic Transmission is fitted

# ENGINE

02-05 Clutch Housing/Automatic Transmission Adaptor & Sump	Part No	
	Triumph	Rimmer Bros
Drain plug	114774	22G2115
Rear crankshaft oil seal	143148	143148
Housing & rear crankshaft oil seal	143149	143149
Gasket - housing to block	143845	143845
Bracket - clutch housing	157227	157227
Clutch housing extension strap	157228	157228
Sump pan	214574	214574
Sump gasket	214580	AJM561
Engine plate - manual transmission	402750	402750
Engine plate - automatic transmission	402762	402762
Dowel	DP0610	DP619
Bolt	HB0812	GHF104
Nut	HN2008	GHF201
Nut	HN2009	GHF202
Setscrew - housing to block	HU0706	GHF117
Setscrew - housing to block	HU0707	SH604071
Setscrew (plate to cylinder block)	HU0806	GHF120
Setscrew	HU0857	HU857
Setscrew	HU0908	GHF105
Setscrew	MA0805	SH605041
Washer - lock	WL0207	GHF331
Washer - lock	WL0208	GHF332
Washer - lock	WL0209	GHF333
Washer - plain	WM0059	WM59
Washer - plain	WP0129	WP129