


# INE - Distributor and Drive Shaft



fitted to anti-air pollution Engines  
 1 to anti-air pollution Engines only  
 1 up to Engine No. LF20,000E only  
 1 from Engine No. LF20,001E and future.  
 1 from Engine No. LE1E and up to LE10,000E only  
 1 from Engine No. LE20,001UE and future.  
 breakdown details see plates 02-83, 02-84, 02-85

## ENGINE

02-09 Distributor & Drive Shaft	Part No	
	Triumph	Rimmer
Oil pump drive shaft	144764	144764
Distributor - to engine no LF20000E, fitted to anti-air pollution engines only	217094	
Distributor - to engine no LF20000E, not fitted to anti-air pollution engines	217435	
Distributor - from engine no LF20000E, fitted to anti-air pollution engines only	218977	
Distributor - from engine no LF20000E, not fitted to anti-air pollution engines	219089	219089R
Thrust washer	517912	
O-ring	517913	517913
Tension pin	517914	517914
Gear	519595	519595
Setscrew - hex head	HU0706	GHF117
washer - lock	WL0207	GHF331
Washer - plain	WP0007	WC701121