

STEERING

02-53 Wheel & Column	Part No	
	Triumph	Rimmer Bros
Bush	136936	136936
Nut	138466	138466
Washer - wavy	150376	150376
Indicator canceller clip	150815	150815
Bearing housing	152552	152552
Thrust washer	152553	152553
Bearing	152554	152554
Spacer	152555	152555
Column bush	153040	153040
Washer/spacer	153816	153816
Wiring harness channel	154371	154371
Outer column	215807	215807
Inner shaft/column	215811	215811
Steering wheel - to commission no ?	311242	311242
Steering wheel - to commission no ?	313149	
Washer - serrated	517480	517480
Washer - plain	517481	517481
Circlip	518329	518329
Boss pad	627321	627321
Spacer	628440	628440
Wiring harness cover	818181	818181
Bolt	HB0822	BH605221
Nut	HN2005	HN2005
Housing retaining screw	KT4502	KT4502
Channel locating screw	PT0503	PX505
Setscrew	PX0504	PX504
Setscrew	PX0513	PX513
Nut - nyloc, thin	TN3208	GHF272
Washer - shakeproof	WK7605	WK7605
Washer - shakeproof	WN0705	WF702101
Washer - plain	WP0005	WP5
Washer - plain	WP0041	WB600121
Grommet		154408
Bolt		BH604111
Nut - nyloc		GHF221