


# ELECTRICAL EQUIPMENT - Front Side / Flasher and Repeater Lamps



NOTE					
215023	SIDE AND FLASHER LAMP FRONT R.H. (white side/amber flasher)	1 off	215172	SIDE AND FLASHER LAMP FRONT R.H. (amber side/amber flasher) (U.S.A. markets only)	1 off
215024	SIDE AND FLASHER LAMP FRONT L.H. (white side/amber flasher)	1 off	215173	SIDE AND FLASHER LAMP FRONT L.H. (amber side/amber) (U.S.A. markets only)	1 off
⊙ 215174	SIDE AND FLASHER LAMP FRONT R.H. (white side/white flasher)	1 off	*156948	MARKER LAMP AND REFLECTOR AMBER (U.S.A. markets only)	2 off
⊙ 215175	SIDE AND FLASHER LAMP FRONT L.H. (white side/white flasher)	1 off	Items marked thus * are for U.S.A. only		
153004	FRONT REPEATER LAMP	2 off	⊙ Fitted up to Commission No.	only	
⊙ 218675	SIDE AND FLASHER LAMP FRONT R.H.	1 off	⊙ Fitted from Commission No.	and future	
⊙ 218676	SIDE AND FLASHER LAMP FRONT L.H.	1 off			
All markets except U.S.A. comprising items marked thus ⊙					

# ELECTRICAL EQUIPMENT

03-13 Front Side/Flasher & Repeater Lamps	Part No		
	Triumph	Lucas	Rimmer Bros
Gasket	150627	54579121	150627
Gasket	150652	54579080	150652
Lamp fixing clamp	152013	54579082	152013
Lamp fixing clamp - USA only	152013		152013
Front repeater lamp	153004	54823A	153004
Marker lamp & reflector - USA only	156948	56273A	156948
Side & flasher lamp - RH, white side & amber flasher	215023	52951A	215023
Side & flasher lamp - LH, white side & amber flasher	215024	52592A	215024
Side & flasher lamp - RH, amber side & flasher, USA only	215172	52954A	
Side & flasher lamp - LH, amber side & flasher, USA only	215173	52953A	
Lens assembly - RH, Italy, white side & white flasher, to commission no ?	215174		
Lens assembly - LH, Italy, white side & white flasher, to commission no ?	215175		
Side & flasher lamp - RH, Italy, white side & white flasher, from commission no ?	218675	52951 & 54584057	
Side & flasher lamp - LH, Italy, white side & white flasher, from commission no ?	218676	52952 & 54584061	
Washer	503581	188330	WL205
Washer - USA only	503581		WL205
Nut	515049	54131266	NH105041
Nut - USA only	515049		NH105041
Screw - lens to base	515059		515059
Screw - lens to base - USA only	515059		515059
Gasket - RH, USA only	517820		
Gasket - LH, USA only	517822		
Screw - lens to base	518800		518800
Interior bulb holder - USA only	518801	54570280	
Lens seating gasket - USA only	518803		
Lens assembly - USA only	518806	54579802	518806
Bulb holder	518807	54575976	
Bulb holder - USA only	518807	54575976	
Lens assembly - LH, white side & amber flasher	518811	54579809	518811
Interior bulb holder - flasher	518812		
Interior bulb holder - side	518813		
Lens assembly - RH, white side & amber flasher	518814	54579808	518814
Lens assembly	519885	54580512	519885
Reflex reflector assembly - USA only	520353	54582801	520353
Bulb - USA only	GLB380	380	GLB380
Bulb - flasher	GLB382	382	GLB382
Bulb	GLB501	501	GLB501
Bulb - USA only	GLB504	504	GLB504
Bulb - side	GLB989	989	GLB989
Nut	HN2005		HN2005
Lens assembly - RH, amber side & flasher, USA only	UKC1653	54579810	
Lens assembly - LH, amber side & flasher, USA only	UKC1654	54579810	
Washer - shakeproof, external	WE0605		WE702101
Washer - plain, light	WP0005		WP5