


AUTOMATIC TRANSMISSION-Torque Converter, Casings, Filler Pipe, etc.



NOTE			
*518372	Transmission Unit and Torque Converter Assembly (Serial No. GEZ 1 onwards)	1 off	☒ 521054 Kit, Planetary Set, Sun gear bearing and Plate 1 off
†521126	Transmission Unit and Torque Converter Assembly (Serial No. 3831001 onwards)	1 off	● 513483 Kit, Planetary set, Sun gear Bearing and Plate 1 off
SERVICE KIT			
513612	Kit, service rubber ring and oil seal	2 off	* Fitted up to Commission No. LF2731 only
RTC0370	Kit, service gasket	2 off	† Fitted from Commission No. LF2732 and future
513575	Kit, service sealing and piston ring	2 off	⊙ Fitted up to Commission No. only
513615	Kit, service thrust washer	1 off	● Fitted from Commission No. and future
519126	Kit, valve body spring	1 off	☒ Fitted from Commission No. only
			● Fitted up to Commission No. and future

AUTOMATIC TRANSMISSION (BORG WARNER TYPE 35)

04-17 - Torque converter, casings, filler pipe etc	Part No	
	Triumph	Rimmer Bros
Transmission unit & torque convertor assembly - fitted up to Commission No LF2731	518372	
Transmission unit & torque convertor assembly - fitted from Commission No LF2732	521126	
Reconditioned transmission less bellhousing and torque converter		RS1070R
Service kit, rubber ring & oil seal	513612	
Service kit, gasket	RTC0370	
Service kit, sealing & piston ring	513575	
Service kit, thrust washer	513615	
Kit, valve body spring	519126	
Oil filler pipe assembly	312328	312328
Oil filler pipe assembly	311711	311711
Dipstick	155834	155834
P-clip, breather pipe to bulkhead	515002	AEU1581A
Screw - self-tapping cross recess A-type	YZ3405	YZ3405
Banjo bolt	158336	158336
Washer, banjo bolt	158337	158337
Pipe tie	154774	240431A
Breather pipe, nylon	154775	154775
Tube connector adapter	155950	RTC1883A
O-ring, breather body	143026	RTC26A
P-clip	100148	AEU1581A
Screw - self-tapping cross recess A-type	YZ3405	YZ3405
Setscrew - hex head	HU0904	SH606041
Washer, plain	WP0009	GHF302
Torque converter	309168	309168R
Kick-down cable	216225	216225
Torque convertor housing	519080	519080
Stoneguard	517499	37H3729
Bolt - hexagon head	HB0814	BH605141
Washer, lock	WL0208	GHF332
Bolt - hexagon head	HB0810	BH605101
Washer, lock	WL0208	GHF332
Nut - steel	HN2008	GHF201
Brake anchor pin	519110	519110
Washer, sealing	518027	
Maincase assembly	519127	
Plug	513443	RTC454
Screw & lock washer	513435	
Nut	513445	513445
Grub screw	513444	9870
Gasket, extension	519276	
Extension housing	519123	
Setscrew & washer		601074
Seal	513609	
Seal	RTC0447	
Seal		RTC447
Speedo drive gear	147321	147321
O-ring	148038	148038
Speedometer bearing	147825	140709
Oil seal	108757	NKC105A
Bracket		140710
Adaptor		60246

AUTOMATIC TRANSMISSION (BORG WARNER TYPE 35)

04-17 - Torque converter, casings, filler pipe etc	Part No	
	Triumph	Rimmer Bros
Washer, plain	WP0007	WC701121
Washer, lock	WL0207	GHF331
Setscrew - hex head	HU0757	SH504071
Gasket set		GAB410