

ACCELERATOR CONTROLS

04-77 Carburettor Linkage Manual Transmission	Quantity	Part No	
		Triumph	Rimmer Bros
Mounting bracket assembly - to LF1678E LE924E USA	A/R	152905	152905
Mounting bracket assembly - from LF1678E LE924E USA	A/R	155779	155779
Spacer	1	153241	153241
Abutment	1	154029	154029
Fix	1	FR1207/4	
Setscrew	1	506749	506749
Washer - lock	1	WL205	WL205
Washer - plain	1	500223	500223
Return spring	1	153640	153640
Setscrew	2	518351	518351
Washer - lock	2	WL207	GHF331
Link rod assembly - RH	1	155445	155445
Knuckle joint	3/4		RS1054
Operating lever assembly - to LF1678E LE924E USA	A/R	152908	152908
Operating lever assembly - from LF1678E LE924E USA	A/R	155782	155782
Ball joint	2	147918	147918
Bearing - to LF1678E LE924E USA	A/R	154752	154752
Bearing - from LF1678E LE924E USA	A/R	155780	155780
Operating lever - to LF1678E LE924E USA	A/R	153127	153127
Operating lever - from LF1678E LE924E USA	A/R	155777	155777
Setscrew		518352	518352
Bearing - to LF1678E LE924E USA	A/R	154752	154752
Bearing - from LF1678E LE924E USA	A/R	155780	155780
Link rod assembly - LH, to LF1678E LE924E USA	A/R	152914	152914
Link rod assembly - LH, from LF1678E LE924E USA	A/R	155776	155776
Circlip	1	518308	518308
Washer - lock, to LF1678E LE924E USA	1	WL205	WL205
Nut - to LF1678E LE924E USA	A/R	508268	508268
Nut - from LF1678E LE924E USA	A/R	503627	503627