

ELECTRICAL EQUIPMENT

05-22 Distributor Exhaust Emission	Quantity	Part No			
		Triumph	Lucas		Rimmer Bros
			1971	1973	
Distributor - to LF20000UE	A/R	218087	41337A		
Distributor - from LF20000UE	A/R	218977			
Distributor cap	1	521009	54418661	54424083	
Brush & spring	1	521010	404435	54423521	
Rotor arm		GRA112	54421149	54422044 DRB113	
Contact Breaker points - twin	2	GCS114	54422587 DSB112	54422587 DSB112	GCS114
Screw - breaker contact points	A/R				RS1575
Condenser	1	GSC107	54422586	54422586	GSC107
Base plate - upper	1	520128	54422584	54422584	520128
Base plate - lower	1	520127	54422617	54422617	520127
Cam - to LF20000UE	A/R	521012	54421614		
Cam - from LF20000UE	A/R	UKC1669		54425707	
Spring set - auto advance, to LF20000UE	A/R	521013	54419169		
Spring set - auto advance, from LF20000UE	A/R	UKC1670		54425705	
Weight	2	517177	54413922	54413922	
Shaft & action plate	1	520130	54422810	54422810	
Vacuum unit - to LF20000UE	A/R	521014	54422902		
Vacuum unit - from LF20000UE	A/R	520131		54424241	UKC1674
Driving gear	1	148868	54421966		519595
Tension pin	1	517914			
Thrust washer	1	517912			
O-ring	1	517913	54160267	54160267	517913
Low tension lead kit	1	521016		54958773	521016